









## HIGH ACCURACY

## EASY OPERATION

- Be sure to remove all chips and all from the sensor plate and the base of the HP-50E as well as from the workpiece and tool.
- To move the tool approaching the sensor plate slowly.
- When touching, the "LED" turns on immediately and "H" is just 50.00 mm.(or2")
- LED will not function if batteries are not set in correctly.
- Designed to be used on ferrous.

ORDER NO.	н	STYLE	WEIGHT (kg)	CODE NO.
HP-50EM	50mm	WITH MAGNETIC BASE	0.3	3403-032
HP-100EM	100mm		1.2	3403-033

## **Stainless Steel Base With Magnet**

TOOL PRE-SETTER FOR MACHINING CENTERS. **CNC & STANDARD MILLING MACHINES AND CNC & STANDARD LATHES**